



The EASY KIT contains: Aluminum or steel Sparewheel, wrench, jack, practical carrying bag, gloves, wheel nuts (optional). Each ALCAR Sparewheel wheel is inflated to the maximum permissible pressure and can be fitted immediately.